

WHAT'S INCLUDED:



EZ Coat



***C-Flex is available in two colors, natural gray or white.**

Helpful tip:

Use First Prime (CW500) on high-alkaline concrete or when applying EZ Coat with a roller. It improves application, reduces roller marks, and helps minimize efflorescence. Always prep the surface the day before with Classic Super Eco Etch cleaner.



WHAT YOU'LL NEED:



Distilled water



Paddle mixer



Mixing bucket



Mesh strainer bag

Recommended application tools:



***Regular concrete:
18" 3/8" nap roller**

***Stamped concrete:
18" 1/2" nap roller**



**Wagner 3500
OR
Wagner 2500**

Step-by-step application video available on our YouTube channel.

Step 1

Concrete must be fully prepped and cleaned one day in advance with Classic Super Eco Etch Cleaner. Instructional video available on YouTube.

Step 2

In a 2 gallon bucket, mix the **Primer** with distilled water. (measurements: 3 part water to 1 part primer)



Step 3

While mixing, slowly add the **C-Flex** cement into the bucket. Continue mixing thoroughly for 4–5 minutes. If you're using an integral color, this is the time to incorporate it.



Step 4

After mixing, run the **EZ Coat** through a mesh strainer (to rid of any clumps) and into your application tool. (Paint pan, or hopper gun). You are now ready to apply **EZ Coat**.



Step-by-step application video available on our YouTube channel.